

Replacing a treadmill incline motor

1. Turn the power switch off
2. Disconnect incline motor wiring from controller.
3. If possible, fold the machine up.
4. Turn the treadmill onto its side. (This is to take the pressure off of the rack)
5. Remove bolt from incline tube on the bottom side of the treadmill.
6. Remove bolt from the top of the incline motor and remove the motor.
7. Install new motor and insert bolt at the top of the incline motor.
8. Reconnect motor wires to controller.
9. Turn power switch on and insert tether cord. The motor will turn until it is a its “zero” position and then stop.
10. Insert bolt into the incline tube on the bottom side of treadmill.
11. Turn treadmill back upright and calibrate.

